アロー 回転灯

[型式] LRP-A、LRX-A

取扱説明書

このたびはお買い上げいただき、誠にありがとうございます。 ご使用に際してはこの取扱説明書をよくお読みのうえ、正しくお使いください。 お読みになったあとは大切に保管し、必要なときにお読みください。

△ 安全上のご注意

表示内容を無視して誤った使い方をしたときに 生じる危害や損害を説明しています。

本機のご使用前に以下の「注意事項」をよくお読みいただき、理解し遵守してください。

取扱いを誤った場合、使用者が死亡又は重症を負うことが 想定される危害の程度をいう。

- ●製品は取扱説明書に記載された範囲内でご使用ください。 感電、火災のおそれがあります。
- ●結線するときは、必ず電源を切ってから行なってください。
- 感電するおそれがあります。 ●本機の分解や改造は行なわないでください。
- 感電するおそれがあります。


取扱いを誤った場合、使用者が傷害を負うことが想定されるか、 又は物的損害の発生が想定される危害、損害の程度をいう。


●使用しない引出し線の先端は、必ず絶縁テープ等で絶縁処理をしてください。 感電、漏電、故障の原因となります。


[おねがい]

- ●電源回路および内部回路保護のため、外部に必ずヒューズを接続してください。
- ●電圧変動の激しい電源(変動率10%を越える電源)や、ノイズ、サージを多く含む電源 (±1000V、1μsを超えるもの)でのご使用は避けてください。
- ●引出し線を強く引っ張らないでください。
- ●IC・LSIを使用しているため、電磁波の強い場所での使用は避けてください。
- ●配線の余分な引き回しや他の電源線などとの併設は避けてください。
- ●供給電源の投入については、電圧が徐々に上昇して定格電圧になるような投入は避けてください。
- ●モータ及びギヤ部へは注油しないでください。
- ●手で反射鏡を回さないでください。

[型式の説明] 例) LRX-100R-A 機種の型式・ LRP: 台座付直付け・回転灯タイプ 製品の電源電圧 グローブの色調 LRX: 直付け・回転灯タイプ 12:AC/DC12V 100:AC100V R:赤 Y:黄 G:緑 B:青 24:AC/DC24V 200:AC200V 48:DC48V








5 [結線方法]

- ●ヒューズは、SEMKO規格認定のものをご使用ください。
- ●本機の制御を半導体で行う場合は、漏れ電流2mA以下のものをご使用ください。




6 [定格]

型 式(※1)	定格電圧	消費電力	突入電流	製品質量
LRP- 12 * -A	AC/DC12V	3.0W 2	2.0A	0.3kg
LRP- 24 * -A	AC/DC24V		2.0A	
LRP-100 * -A	AC100V	4.0W	0.2A	0 Eka
LRP-200 * -A	AC200V		0.2A	0.5kg
LRX- 12 * -A	AC/DC12V	3.2W	2.0A	
LRX- 24 * -A	AC/DC24V			0.3kg
LRX- 48 * -A	DC48V	4.0W		
LRX-100 * -A	AC100V		0.2A	0 Eka
LRX-200 * -A	AC200V		0.2A	0.5kg

140min ⁻¹ (※ 2)
-10°C∽50°C
35%∽85%RH
(結露のないこと)
腐食性ガスのないこと
70m/s² {7.1G} (JIS D1601準拠)
LRP-A:IP43 LRX-A:IP23 LRX-A:IP65(※3) (※3:ラバーベース装着時)

※1 型式の中の「*」は、表示色(赤:R、黄:Y、緑:G、青:B)を表わします。 ※2 100V、200Vタイプは印加電圧に比例して閃光速度が変動します。



[オプション品]

品 名	型 式	適応機種
LRX拡散レンズ	LRX-C	LRP-A
取付L金具	L-2A	
M金具1	M-1	LRX-A

品 名	型 式	適応機種
APポールL	17-300L	
Ø17ポールS	17-300LB	LRP-A
APマグネットシャーシ	M-13	
AXラバーベース	G-101	LRX-A

株式会社デジタル

●出荷に際しましては、十分なチェックをして万全を期しておりますが、万一ご使用中にご不審な点やお気づきのことがありましたら、 コールセンター(シグナリング製品)までご連絡ください。

コールセンター(シグナリング製品)

ナビダイヤル 0570-032010 FAX

06-6613-3130

(祝祭日・弊社休業日を除く)

注文書はFAXまたは書面にてお願いいたします。 【受付時間】月~金 9:00~12:00、13:00~17:00

技術お問い合わせ専用メールアドレス tech-support-signaling@mail.digital.co.jp

【受付時間】メールによるお問い合わせ窓口は24時間受け付けております。 (祝祭日・弊社休業日を除く、24時間以内に返信いたします)

AQT0305I



ARROW BEACON

[MODEL] LRP-A, LRX-A

Instruction Manual

Thank you for purchasing. Please read this instruction manual carefully before installation. Please keep it carefully after having read, and please read when it is necessary

⚠ Precaution

Injury or damage by failure to follow these instructions.

Read and comprehend and follow the instructions below before installing

Warning

Failure to follow these instructions will result in death or serious injury.

- Do not use the product outside instructions in this manual.
- HAZARD OF ELECTRIC SHOCK OR BURN
- Turn off power supply before wiring. HAZARD OF ELECTRIC SHOCK
- Do not disassemble or modify the product outside instructions in this manual. HAZARD OF ELECTRIC SHOCK


Caution


Failure to follow these instructions will result in serious injury or equipment damage.


Provide any unused cord or wire with insulation. DESTRUCTION OR MALFUNCTION OF DEVICE, DESTRUCTION ELECTRIC SHOCK

[Other usage considerations]

- Install a fuse to protect power supply circuit and other internal circuit.
- Do not supply voltage with large fluctuation (more than 10% of the rated voltage) or with noises or surge (more than ± 1000 V, 1μ s).
- Do not pull out the cables or wires.
- Do not install the product with strong electromagnetic waves to avoid malfunction of
- Do not supply power from one power supply to plural products or other devices. Do not keep any cord or wire too loose.
- Do not supply voltage as it comes up to the rated voltage gradually.
- Do not apply oil onto motor or gear.
- Do not rotate mirror by hand.









[LRX-A]

•Fasten screws with frange-nat which are attachee as shown in the right picture. The torque should be 1.0N·m(The thickness should be less than1~8mm for the installing material.)



5 [Wriing Method]

●Please use the one of the SEMKO standard recognition about the fuse.



6 [Specifications]

Model(%1)	Rated Voltage	Power Comsumption	Inrush Current	Mass
LRP- 12*-A	AC/DC12V	3 0///	3.0W 2.0A	0.3kg
LRP- 24 * -A	AC/DC24V	3.000		
LRP-100 * -A	AC100V	4.0W	0.2A	O Eka
LRP-200 * -A	AC200V	4.000	0.2A	0.5kg
LRX- 12*-A	AC/DC12V	3.2W 4.0W	2.0A	
LRX- 24*-A	AC/DC24V			0.3kg
LRX- 48 * -A	DC48V			
LRX-100 * -A	AC100V		0.2A	0 Eka
LRX-200 * -A	AC200V		0.2A	0.5kg

	Flash speed	140min ⁻¹
	Temperrature Range	-10°C∽50°C
	Humidity Range	35%∽85%RH(No freeze)
	Operable atomosphere	No corrosion gas
	Vibration	70m/s ² {7.1G}
	Structure When in stalled in proper direction	LRP-A:IP43 LRX-A:IP23 LRX-A:IP65 (※3) (※3: with "Rubber base)

120°

Ø50

Please make holes for wiring depending on your needs

(AC100V:It should be


more than Ø25mm)

Ø15~30

[Unit:mm]

X1 [*] = Red: R, Yelow: Y, Green: G, Blue: B ※2 Flashes per Minute vary depending on voltage

[Appearance] [LRP-A]



[Optionals]

Item Name	Style No	Model
LRX diffusion lens	LRX-C	1.00.4
Installation L metal	L-2A	LRP-A
Installation M metal	M-1	LRX-A
		•

Item Name	Style No	Model
AS Pole-L	17-300L	
Ø17 Pole-S	17-300LB	LRP-A
AP magnet chassis	M-13	
AX Rubber base	G-101	LRX-A

DIGITAL ELECTRONICS CORPORATION

DIGITAL takes pride in its products. The products are manufactured to the highest standard including the Instruction Manual before shiping out from DIGITAL. However, should original purchaser of these DIGITAL products encounter deficiency or inadequacy, contact DIGITAL's authorized agent or Quality Assurance Section of DIGITAL.

Technical support E-mail address

If you have any questions, about a wiring method / tech-support-signaling@mail.digital.co.jp tallation, please contact it willingly.

[Service hours] I take the inquiry window by the email for 24 hours. (I reply within 24 hours except holiday / we dies non at japanese time)